


Eve Core

BAT=AA*2

VBAT



Chip Ant.

Tact Switch
(factory reset)

LED Red
Reset indicator

Motion sensor
PYD1096
OUT
Sens

adjustable
sensitivity
circuit
Sen0
Sen1
Sen2

Light sensor
TSL25723FN
I2C
INT

Boost IC
TLV61220DBV

VBAT

3.3V

3.3V

Low active

I2C

I2C

Low Enable

1.8V

1.8VP

SPI

JTAG
UART

Debug

MFI3415S3959

SPI Flash
W25Q16DW

16MHz
32.768KHz