



单铜纸
70x110mm

SWISSTEN JUMBO Bluetooth Headsets  Manual	Congratulations on your purchase and thank you for your use of our Bluetooth Headset. In order to start quickly, please read the user guide carefully. Caution: 1. Please turn off the headset and put it into box to avoid damage, scratches or bracket deformation when long time no use. In order to prolong the battery service life, please charge every 6 months. 2. Please charge at first if the headset is left unused for long time. 3. The battery of headset is original and please don't change it by yourself. 4. Please keep the headset under dry place. 5. Please don't put this product into the environment with temperature over than 60℃ or into fire to avoid battery blast accident. 6. Please don't bent or twist the bracket to avoid deformation. 7. Please don't tear down ear-cushions by un-professional person. 8. Don't adjust the volume to a very high level and continued play. If tinnitus occurs, please turn the volume down or stop playing, do not turn the volume up suddenly. Please slowly turn up the volume to avoid hearing damage caused by high volume. 9. Do not use the headset in dangerous place or place where cannot hear the outside sound. Included: The headset contains the following parts: Bluetooth Headset X 1 Manual X 1 3.5mm – 3.5mm audio Cable X 1 USB C Charging Cable X 1  ON / OFF VOLUME+ / NEXT SONG MFB (ANSWER / END PHONE CALL; PLAY / PAUSE) VOLUME- / PREVIOUS SONG 3.5MM AUX MIC LED USB C	Charge the Battery: The headset contains a USB C cable that can be connected to your computer or other device made for USB charging. Plug the TYPE-C end of the included USB cable into the TYPE-C port charger connector under the left ear-cap of the headphone. Plug the other end into a USB port on your computer or other devices made for USB charging. The indicator light will be red while charging. Once fully charged, the indicator light will be blue. Charge time is about 3 hours on an empty battery. Turning unit ON/OFF Slide the ON/OFF button to turn on the unit. The Bluetooth LED indicator will flash blue and red. Slide the ON/OFF button again to turn off the unit. The Bluetooth LED indicator will light off. Pairing: 1. Ensure that your phone or Bluetooth device is switched on. 2. To pair the headset if it has not been previously paired with a device, switch on the headset. The headset enters the pairing mode, and the blue and red indicator light starts to flash alternately. To pair the headset if it has been previously paired with another device, ensure that the previously paired device is switched off. 3. Activate the Bluetooth feature on your phone or Bluetooth devices, and set it to search for Bluetooth devices. 4. Select "Swissten Jumbo" from the list of found devices on your phone or Bluetooth devices. 5. When successfully connected, the blue light turns to continuously lighting. The headset that has been previously paired with another device will automatically connect with the device if the device is power on and within connecting range, if not, the headset will enter standby mode with continuously blue light.	Adjust the volume: Turn the volume up or down by a quick press on the volume +/- key during a call or while listening to music. When the volume reaches to Maximum volume, there is a warning tone. Application: Swissten Jumbo can make and receive calls hands-free with your compatible mobile phone and listen to music from a compatible Bluetooth device, but they should be with 10 meters (33 feet) of each other. The headset is compliant with the Bluetooth Specification 5.0 support the following profiles: Headset Profile (HSP) V1.6, Hands-free Profile (HFP) V1.7, Advanced Audio Distribution Profile (A2DP) V1.3, and Audio Video Remote Control Profile (AVRCP) V1.5 input rating 5V DC, 0.5A Calls: To make a call, use your mobile phone in the normal way when the headset is connected to it. Quickly Press the MFB twice to call the last number in the call list. When a phone call comes in, quickly press the MFB to answer it, or long press about 1.5 seconds to reject the call. Call is ended when short press MFB during a call. Listen to Music: To listen to music, connect the headset to phone or compatible Bluetooth devices that support A2DP Bluetooth profile. The available music functions depend on your Bluetooth devices. If you receive or make a call while listening to music, the music is paused until the call ends. To play a song, select in the music player and press the Play/Pause key on the headset. To pause or resume playing a song, press the Play/Pause key. To select the next song during playback, long press "3 seconds" + ". To select the previous song, long press for 3 seconds " - ". To increase the volume, quickly press " + " key, there will be beep town when reaching max volume. To decrease the volume, quickly press " - " key.	Disconnect the Headset: To disconnect the headset from your device, switch off the headset, or disconnect it in Bluetooth menu of your device. Reconnect the headset: To connect the headset to the phone or Bluetooth devices that you have last used with it, switch on the headset, or make the connection in the Bluetooth menu of your device. Passive Mode: You can use Swissten Jumbo as a wired headphone to save batteries. Simply connect one end of the 3.5mm jack to 3.5mm audio cable to the bottom of the left ear cup to your MP3 player. Inserting an audio cable disable the wireless functionality. Low Battery Warning: At power on condition, when battery voltage is lower than 3.0V, there will be a warning beep every 60 seconds. Power-Off at Low Battery Condition: At power on condition, when battery voltage is lower than 2.9V, the headset will switch off automatically. Note: When using the headphone on a airplane, please use the 2-pins aircraft adapter.	Specification: Version: Bluetooth V5.3 + EDR (ATS chipset) Frequency Range: 2.402 GHz - 2.480 GHz ISM Band Transmission: CLASS 2 Channels: 79 channels of 1Mhz BW Operation rande: 10 m Frequency Responses: 20 Hz - 20 kHz Speaker sensitivity: 98 dB ± 3 dB Speaker diameter: 40 mm Speaker impedance: 32 Ω Signal to Noise rate: 80 dB Driver output: 2 x 30 mW Status Indicator: LED<blue> flash slowly (under Bluetooth mode) Compatibility: Suitable for HFP, HSP, A2DP, AVRCP Battery: Li - polymer battery 300 mAh Charging time: 2 hours Input: 5 V DC 0.3 A Working time: max. 16 hours	SWISSTEN JUMBO Bluetooth Headsets  Manual
SWISSTEN JUMBO BLUETOOTH SLUCHÁTKA  NÁVOD	Děkujeme, že jste si zakoupili naše sluchátka SWISSTEN JUMBO. Než začnete sluchátka používat, přečtěte si prosím pečlivě uživatelský návod. Upozornění 1. V případě, že nebudete sluchátka delší dobu používat, vložte je do krabičky, abyste zabránili jejich poškození. Pro prodloužení životnosti baterie, sluchátka nabijte minimálně jednou za 6 měsíců. 2. Pokud jste nějaký čas sluchátka nepoužívali, nabíjejte je delší dobu. 3. Baterii sami nevměňujte. 4. Nepoužívejte ani neskladujte sluchátka ve vlhku. 5. Sluchátka nevystavujte teplotám nad 60 °C. 6. Abyste se zabránili zničení sluchátek, tak s nimi nekrutíte ani je neohýbajte. 7. Nestírávejte ušní polštářky. 8. Používání sluchátek při vysoké hlasitosti může poškodit sluch. 9. Nepoužívejte sluchátka v nebezpečných místech a v místech, kde je potřeba slyšet okolní zvuky. Balení obsahuje: 1. Sluchátka SWISSTEN JUMBO 2. Uživatelská příručka 3. Kabel AUX-IN 3,5mm JACK / 3,5mm JACK 4. Kabel USB-USB-C  zapnutí/vypnutí zvýšení hlasitosti/datší skladba MFB multifunkční tlačítko (přijem hovoru/ukončení hovoru, přehrát hudbu/zastavit hudbu) snížení hlasitosti/předchozí skladba LED kontrolka AUX - 3,5 mm jack mikrofon Dobijecí USB-C konektor	Nabíjení baterie Kabel, který je v balení připojte do USB portu počítače nebo USB nabíječky, která je určená pro nabíjení sluchátek a poté do dobíjecího konektoru sluchátek USB-C. Když se sluchátka začnou nabíjet, začne svítit červená kontrolka. Když jsou sluchátka nabitá, kontrolka svítí modře. Nabíjení může trvat až 3hodiny. Zapnutí/vypnutí Přepněte přepínač ON/OFF pro zapnutí sluchátek. Kontrolka začne blikat střídavě modře a červeně. Při zpětném přepnutí přepínače se sluchátka vypnou a kontrolka zhasne. Párování 1. Zapněte sluchátka 2. Párování sluchátek, která dříve nebyla spárována s jiným zařízením – sluchátka se přepnou do párovacího módu a kontrolka začne blikat střídavě modře a červeně. Párování sluchátek, která dříve byla spárována s jiným zařízením- zajistěte, aby mělo předchozí zařízení vypnuté Bluetooth nebo aby bylo z dosahu sluchátek. 3. Ve svém smartphonu vyhledejte bluetooth zařízení (postup najdete v návodu svého smartphonu). Smartphone najde sluchátka „SWISSTEN JUMBO“. a připojte se k nim. 5. Kontrolka začne svítit modře. Sluchátka, která jsou spárována se zařízením, se po zapnutí automaticky k zařízení připojí bez potřeby párování.	Změna hlasitosti Hlasitost se mění rychtými stisknutími tlačítek +/- v průběhu hovoru nebo poslechu hudby. Když jsou sluchátka na maximu hlasitosti, vydají varovný tón. Použití Sluchátka Swissten Jumbo mohou uskutečňovat a přijímat hovory s kompatibilním mobilním telefonem a poslouchat hudbu z kompatibilního zařízení Bluetooth. Zařízení by neměla být od sebe vzdálena víc jak 10 metrů. Sluchátka jsou v souladu s Bluetooth 5.0 a podporují tyto profily: HSP V1.6, HFP V1.7, A2DP V1.3 a AVRCP V1.5. Vstupní napětí 5V DC 0,5A. Hovory Dvakrát krátce stiskněte tlačítko >= (MFB) a vytvoří se poslední volané číslo. Pro příjem hovoru stiskněte jednou tlačítko >= (MFB) a pro odmítnutí hovoru tlačítko >= (MFB) dlouze stiskněte (cca 1,5s). Probihající hovor se ukončí krátkým stisknutím tlačítka >= (MFB). Poslech hudby Chcete-li poslouchat hudbu, připojte sluchátka k telefonu nebo kompatibilnímu zařízení Bluetooth, které podporuje profil A2DP Bluetooth. Dostupné hudební funkce závisí na zařízení Bluetooth. Pokud během poslechu hudby přijmete nebo uskutečníte hovor, hudba se pozastaví, dokud hovor neskončí. - Chcete-li přehrát skladbu, vyberte ji v hudebním přehrávači a stiskněte tlačítko Play/Pause na sluchátkách. - Chcete-li přehrávání skladby pozastavít nebo v něm pokračovat, stiskněte tlačítko Play/Pause. - Chcete-li během přehrávání vybrat další skladbu, dlouze stiskněte na 3 sekundy " + ". - Chcete-li vybrat předchozí skladbu, dlouze stiskněte na 3 sekundy tlačítko " - ". - Chcete-li zvýšit hlasitost, rychle stiskněte tlačítko " + ", při dosažení maximální hlasitosti se ozve pípnutí. - Chcete-li snížit hlasitost, rychle stiskněte tlačítko " - ".	Odpojení sluchátek Pro odpojení sluchátek vypněte sluchátka nebo vypněte bluetooth v MENU zařízení. Opětovné připojení sluchátek K poslednímu připojenému zařízení se připojíte zapnutím sluchátek nebo přes MENU bluetooth Vašeho zařízení. Pasivní mód Sluchátka SWISSTEN JUMBO můžete používat jako drátová sluchátka a setít tak baterie. Propojte sluchátka se zařízením přiloženým kabelem AUX-IN 3,5mm JACK. Vložení audiokabelu vypne bezdrátovou funkci. Nizký stav baterie Když poklesne napětí baterie pod 3V, sluchátka vydají každých 60s varovné pípnutí. Vypnutí při nízkém stavu baterie Když poklesne napětí baterie pod 2,9V, sluchátka se automaticky vypnou.	SPECIFICATION: Verze Bluetooth V5.3 + EDR (ATS chipset) Radiofrekvenční pokrytí: 2.402 GHz - 2.480 GHz ISM Band Přenos: třída 2 Kanály: 79 kanálů v 1Mhz BW Dosah: 10 m Frekvence: 20 Hz - 20 kHz Citlivost reproduktoru: 98 dB ± 3 dB Průměr reproduktoru: 40 mm Impedance: 32 Ω Odstup signálu od šumu: 80 dB Výkon: 2 x 30 mW Led indikátor: pomalé modré blikání - připojeno k Bluetooth Bluetooth profily: Suitable for HFP, HSP, A2DP, AVRCP Baterie: Li - polymer battery 300 mAh Čas dobíjení: 2 hours Parametry nabíjení USB-C: 5 V DC 0.3 A Doba poslechu: maximálně 16 hodin Voděodolnost: IPX3	SWISSTEN JUMBO BLUETOOTH SLUCHÁTKA  NÁVOD