

**SAFETY INSTRUCTIONS**

Before using your Air Beats Mini, please read the user manual carefully and keep it somewhere safe for your later reference.  
Do not use your Air Beats Mini if the product is clearly defective.  
This product is not a toy and is not intended for use by children under the age of 14.

**Warnings and Precautionary Measures**

Do not listen to music at high volumes for an extended period.  
Keep out of reach from children and pets.  
Contains small parts which may be a choking hazard.



Attention: Not suitable for children under the age of three.

To avoid the risk of fire or electric shock, do not expose the product to water or moisture.  
Do not use Air Beats Mini in the rain or in places where the speaker may come into contact with drops, or splashes of water or other liquids. Do not place objects filled with liquids on the product.  
Do not install the product near any heat sources such as radiators, heater coils, stoves, or other equipment (including amplifiers) that produce heat.



Do not place Air Beats Mini near open flames. Do not block any ventilation openings. Unplug Air Beats Mini from the wall socket during a lightning storm or if not in use for an extended period.  
Speaker is equipped with magnets, therefore it is not recommended for those who have a cardiac pacemaker or implanted defibrillator.

**DISPOSING OF OLD DEVICES AND ELECTRONIC DEVICES****Separate Collection of Old Equipment**

Electrical and electronic equipment that has become waste is called old equipment. Owners of old equipment must dispose of it separately from unsorted municipal waste. Old devices in particular should not be disposed of with household waste, but in special collection and return systems.

**Batteries and Accumulators**

As a rule, owners of waste equipment must separate spent batteries and accumulators that are not enclosed in the waste equipment from the waste equipment before handing it over at a collection point. This does not apply if WEEE is prepared for reuse with the participation of a public waste management authority.

**Options for the Return of Old Equipment**

Owners of old appliances from private households can dispose of charge at the collection points of the public waste management authorities or at the take-back points set up by manufacturers or distributors as defined by the ElektroG.

Stores with a sales area of at least 400m<sup>2</sup> for electrical and electronic equipment and those grocery stores with a total sales area of at least 800m<sup>2</sup> that offer electrical and electronic equipment several times a year or on a permanent basis and make it available on the market are subject to the take-back obligation. This also applies in the case of distribution using means of distance communication, if the storage and shipping areas for electrical and electronic equipment are at least 400m<sup>2</sup> or the total storage and shipping areas are at least 800m<sup>2</sup>. Distributors shall generally ensure take-back by providing suitable return facilities at a reasonable distance from the respective end user.

The possibility of returning an old device free of charge exists for distributors who are obliged to take it back, among other things, if a new similar device that essentially fulfills the same functions is delivered to an end user. If a new appliance is delivered to a private household, the similar waste appliance can also be handed over there for collection free of charge; this applies in the case of distribution using means of distance communication to appliances in categories 1, 2 or 4 as defined in Section 2 (1) of the Electrical and Electronic Equipment Act, namely „heat transmitters“, „display screen equipment“ or „large appliances“ (the latter with at least one external dimension exceeding 50 centimeters).

End users are asked about their intention to return such equipment when they conclude a purchase contract. In addition, there is the possibility of free return to the collection points of the distributors, independently of the purchase of a new device, for such old devices that are not larger than 25 centimeters in any external dimension, limited to three old devices per type of device.

**Privacy Notice**

Old devices often contain sensitive personal data. This applies in particular to information and telecommunications technology devices such as computers and smartphones. In your own interest, please note that each end user is responsible for deleting the data on the old devices to be disposed of.

**Meaning of the „Crossed-Out Trash Can“ Symbol**

This symbol means that the product must not be disposed of with household waste, but must be taken to an appropriate collection point for recycling. Proper disposal and recycling helps to protect natural resources, health and the environment. For more information on the disposal and recycling of this product, contact your local municipality, waste disposal service or the store where you purchased this product.

**CE Compliance Statement**

Vonmählen hereby declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU and all other applicable EU directive requirements. The complete declaration of conformity can be found at [www.info.vonmaehlen.com/manual/air-beats-mini](http://www.info.vonmaehlen.com/manual/air-beats-mini)

**UKCA Compliance Statement**

This product complies with all applicable Electromagnetic Compatibility Regulations 2016 and all other other applicable UK Directives. The complete Declaration of Conformity can be viewed at [www.info.vonmaehlen.com/manual/air-beats-mini](http://www.info.vonmaehlen.com/manual/air-beats-mini)

**Frequency range: 2402 MHz - 2480 MHz**  
**Max. radiated transmitting power: 2 dBm**

**Sound**

Frequency Response	80 Hz - 20 KHz
Full Driver Range	180 Hz - 15 KHz
Impedance	4 Ω
Sound Pressure Level	82 dB ± 3 dB

**Battery**

Battery Type	Integrated rechargeable lithium-ion battery 3.7 V / 8.14 Wh
Battery Capacity	2200 mAh
Music Playtime	Up to 13 hours
Battery Charge Time	5 hours

**CARE AND MAINTENANCE**

Do not drop or shake Air Beats Mini.  
Keep your Air Beats Mini dry.  
Store in a cool, dry place.

Do not expose to extreme temperatures above 40°C (104°F) to avoid corrosion or deformation.  
Do not use the product outdoors during thunderstorms.  
Store your Air Beats Mini in a clean, dust-free environment.  
Do not make unauthorized alterations to the product.  
Only use recommended attachments/accessories and other parts recommended by Vonmählen.  
Only use this product with an approved power supply.  
Do not use polish, detergents, or harsh soaps on the speaker. Only clean with a dry cloth.

**Bluetooth®-Connectivity**

Bluetooth® Version	5.0
Bluetooth® Frequency Range	2402 MHz - 2480 MHz
Bluetooth® Profiles	HFP V1.5; A2DP V1.3; AVRCP V1.5
Bluetooth® Range	10m
Signal-to-Noise Ratio	> 60 dB

**LEGAL NOTICES AND TRADEMARKS**

The Bluetooth® trademark and logos are registered trademarks of Bluetooth SIG, Inc., and the use of these trademarks by Vonmählen GmbH are permitted through a licensed third party. Other trademarks and trade names are the property of the respective owners.

**NEED MORE INFORMATION?**

Visit [www.info.vonmaehlen.com/manual/air-beats-mini](http://www.info.vonmaehlen.com/manual/air-beats-mini) for detailed product information regarding Air Beats Mini. You will also find information about current orders and promotions as well as the FAQ section about Vonmählen products and services.



vonmaehlen



@vonmaehlen

**VONMAHLEN GmbH**

Vor dem Bardowicker Tore 49 | 21339 Lüneburg, Germany | +49 4131 22 09 50  
[service@vonmaehlen.com](mailto:service@vonmaehlen.com) | [www.vonmaehlen.com](http://www.vonmaehlen.com)